



# How to Install ADISRA™ SmartView

ADISRA™ SmartView requires .NET 5 to run. Please follow the direction below to install the .NET 5 and ADISRA™ SmartView.

1. Install the ASPNET Core Runtime (x64 or x86) located in the installation folder.



2. Install the Windows Desktop RunTime (x64 or x86) located in the installation folder.



3. After installing the above frameworks, click on the executable "ADISRA SmartView.exe" to install the ADISRA™ SmartView. Run the installer as administrator.

